

Title: Photovoltaic support unloading pictures and text

Generated on: 2026-03-07 04:58:41

Copyright (C) 2026 ELALMACEN SOLAR. All rights reserved.

---

How to unload & store PV modules?

**UNLOADING, UNPACKING & STORAGE** At receipt of PV modules, verify the product details as it had been ordered. Packing list pasted outside the box contains all details including the serial no of modules. It is recommended to unload the packing box by using forklift only.

How to stacked PV modules?

The unpacked PV modules should be placed flat on the pallet. The stacked quantity should not be more than 16 pieces. Be sure to place the first module with the front side up and the others with the front side facing down. Step 1: Check the pallet list for all module information. Step 2: Cut the green straps.

How to transport multiple PV modules?

Mechanical equipment should always be used when transporting multiple modules. The unpacked PV modules should be placed flat on the pallet. The stacked quantity should not be more than 16 pieces. Be sure to place the first module with the front side up and the others with the front side facing down.

How do PV modules generate electricity?

**GENERAL INFORMATION & SAFETY** PV modules generate electricity upon direct exposure to light, which can produce electrical shock. Use of insulated tools and gloves is recommended while working with modules in sunlight. No metallic contacts should be on the human body.

It's best to stage the pallets in a flat, open and dry location when unpacking, and position the pallets next to a solid, self-standing support structure, such as a tracker post or wall -- the taller and sturdier ...

To ensure the safety of loading, unloading, unpacking. and storage of PV modules, please read this manual carefully. When you need to unpack and install the modules, you can search and download ...

The photovoltaic support structure must be firm and reliable and can withstand such external effects as atmospheric erosion, wind load and so on. It should have safe and reliable installation, can achieve ...

When unloading, the whole modules should be balanced as far as possible, the forklift arm should be kept relatively horizontal, and the forklift truck should fork the modules out of the container slowly and ...

Mechanical and electrical installation of photovoltaic modules should refer to the corresponding regulations, including electrical law, construction law and electrical connection requirements. ...

# Photovoltaic support unloading pictures and text

Source: <https://www.elalmacendelaireacondicinado.es/Tue-12-Aug-2025-35148.html>

This manual provides comprehensive guidelines for the safe and efficient Unloading and storage of solar photovoltaic (PV) modules manufactured and supplied by JAKSON Engineers Limited.

Unpacking of PV modules should always be done in the vertical manner by two persons as shown in the diagram. Also care should be taken for falling over one module to the other inside the packing box.

This short video explains best practices for loading, banding, and unloading solar modules with your PVpallet Series X. Note that banding is always necessary to properly secure your PV ...

Website: <https://www.elalmacendelaireacondicinado.es>

